

1


Print from PDF

Prepare your file as an Adobe PDF and print the file from Adobe Acrobat.


2

Set your Paper Size

1. Select [Page Setup] and set
2. Format for: to “L1000_Color4”
3. Set your [Paper Size...]
4. For Standard Size Papers(US Letter, US Legal, Tabloid, 17 x 22, etc) You must set the paper feed to “Sheet”
Note: There are sizes for 30 x 24in, 8 x 10in. 8 x 10in is the smallest paper size.
5. For Custom Paper Sizes, select “Manage Custom Sizes...” and specify the Width and Height of your paper.
Keep in mind that the dimensions entered are relative to the way the paper is inserted into the printer.
Next set the Non-Printable Area to L1000_Color4.
6. Select, [Okay] to close the dialogue



For Standard Size Paper Stocks




For Custom Size Paper Sheets

3

Check Advanced


Next, select [Advanced] dialogue, and make sure that:“Print as Image” is unchecked/off
Then continue to Color Management and make sure it is set to “Same as Source(No Color Management)”



4

Select Media/Paper Type

1. Select “Printer...” from the
2. Select the middle dropdown menu(typically labelled Layout) and Select, “Printer Settings”
3. Select [Media Type] and select the closest paper to what you are using
We suggest choosing from the Fine Art selections unless you are printing on photo quality paper. If you need help feel free to ask a Tech.



Make sure that

- Page Setup:** Sheet
(very important if using a Custom Paper Size)
- Color Mode:** Adobe RGB
- Ink:** Color/B&W Photo
- Print Quality:** at least 720dpi

Select Print to Close the Printer Dialogue and Select Print again to send your job to the Printer, a login dialogue will pop up for your Percut Credentials